

Step Guide

Yealink



I would strongly recommend doing these steps with the repeater next to the base and once synced move it to where required

- Plug the repeater into an AC outlet.
 POWER LED turns green and DECT LED flashes red.
- 2. Set the handset in RT30 repeater mode at the path:

Settings->SystemSettings->Repeater Mode.

3. Set the base station in registration mode

(Long press the paging key on the base station till the first LED flashes green). If base station is found, DECT LED will flash orange. When DECT LED turns green/orange, the registration to base station is successful.